

Kit Assembly Instructions

Model: for steel cable system

Use: direct fixing

Assembly Tools

- Hexagonal male key 2mm
- Hexagonal male key 3mm
- Screw
- Alignment instruments
- Screwdriver

Installation Steps

1. Dig holes on the wall. Screw ② into ① (01 on the top, 02 on the bottom).
2. Insert the cable into ① (01), screw ④ (Hex Screw) into ① (01) to hold the cable (anti-clockwise rotation).
3. Insert the cable into ⑤, ⑥, ⑦ (downwards the screw thread of ⑤). Screw ⑧ (2 Hex Screws) into ⑦ (cable holder) to hold the cable.
4. Screw ⑤ into ① (02).

