
Belt Replacement Instructions

1.





Unscrew the 4x bottom most screws

2.



Slide the old Cartridge out

IMPORTANT:

<u>Do NOT</u> Remove

Top screws

3.





Insert the new cartdridge and screw back onto the post