




1. Using the allen key provided, loosen the Cable from the Panel Holder.




Measure the Cable and pull taut, then using cable cutters or pliers, cut the Cable to desired length.




3. Reattach the Panel Holder to the Cable and tighten the Grub Screw.






4. Fasten the Ceiling Anchor to the ceiling using the screw provided.



Insert the end of the Cable with the Cable Stop into the Ceiling Anchor and fasten both Grub Screws.



Loosen the Grub Screw on the Panel Holder and place your panel into the holder. Then tighten the Grub Screw to secure the panel to the Panel Holder.

