


# One Fabric Exhibition Stand- Instructions

**WARNING! DO NOT FORCE CLOSED.**


To avoid damage, all hooks must be disconnected before collapsing frame.




1. Remove the frame from the protective case and place on a clean flat surface with the velcro on the top.




2. Carefully spread the frame out until it is fully extended. The attached hooks then need to be linked to each other.




3. Starting on one side, attach the velcro side of the graphic to the velcro on the frame. Overlap velcro of graphic about 6mm on all sides on the velcro on the frame.




4. Work continuously in one direction across the frame until the graphic entirely covers the frame.



5. Adjust where needed for a taut fit right across the frame.



6. **OPTIONAL**  
Attach lights to top of the frame by sliding the plastic X-Blocks under the frames cross sections.



# Case to Counter - Instructions



1. Open the container and remove the fabric print.



2. Remove the timber (MDF) board from the centre of the case.



3. Close the lid of the lid and secure the container.



4. Pull the fabric print over the container.



5. Pull and secure the velcro strap at the top of the unit.



6. Place the timber board onto the top on the print container and push down to secure.

