




IPAD360BK / IPD7GBK / IPAD360WT / IPD7GWHT Instructions




Remove the 4 screws and bottom piece from case.




Slide iPad into the case.




Replace the bottom piece




Replace the 4 screws.




Simple assembly




Press buttons, attach shell, release buttons, and spin until you hear the click




Rotates 360°, tilts for angle adjustment, and reversible view




Pivots 360°




Wrap cable around a secure post, and pass the lock through the hoop at the end of the cable.



Insert the cable lock into the security slot on the shell.



Turn key clock-wise to lock



Remove key