



## FREE STANDING PRODUCT DISPLAY STAND

(Only for selected models)

### STEP 1

Remove the cover at the top of the pole  
(All of our sage accessories use the channels on the pole to attach the accessories).

(a) Simply loosen connector with the screw located at the top of the bar on the shelf then slide the connectors along the channel.

(b) Tighten screw at the desired height.

### STEP 2

To attach clip frame slide the screws and the connectors along the groove in the display pole. Adjust to appropriate height and tighten.