
# Model: CI WI B14



# (A) Description and Function:

The Charging Station is made for charging up to 8 mobile devices simultaneously.

Features 645 x 474mm Poster Backlit lightbox for advertising purposes.

#### (B) Intended Use:

It is not allowed to use the device in other ways than described in chapter "Description and Function" Use this device only in dry interior rooms. The symbol with the house reminds you of that. If you do not attend to these regulations and notes on safety, it might causes fatal accidents, injuries and damages to persons and property.

#### (C) Notes on Safety:



ATTENTION! Ensure product is fully assembled prior to connecting to power. There is a risk of electric shock and short circuit!

. This product is not a toy and is not meant for children, because it contains small parts which can be swallowed and can injure when used inappropriately!

- · Please install the system and devices attached to it in a way that persons cannot be injured, or objects not be damaged for example by dropping and stumbling
- · Please remove the packing materials, because children may cut themselves on them while playing. Furthermore, there is a risk of swallowing and inhalation of incidentals and insulating material.
- · Avoid places with high temperatures, or humidity, or places which might come into contact with water.
- Do not install the product close to openings of air conditioners, or at places with an excessive amount of dust, smoke or vibrations.
- · Place the product only on horizontal and flat surfaces to avoid
- · Do not modify and alter the product and any accessories! Make sure you also read the Chapter "Warranty and Liability"
- . Do not use any damaged parts
- · Plug and unplug all cables / adaptors slowly and carefully.
- · During transport, observe the details listed in the Chapter "Specifications", and implement measures suitable for transport, e.g. use the original package.
- · For questions, defects, mechanical damages, malfunctions, and other functional problems which cannot be resolved by this manual, please contact your dealer for repair or replacement, as described in the Chapter "Warranty and Liability".
- · Mind Chapter "Specifications".
- · Please also observe the terms of use decribed in the Chapter "Intended Use"


## D Package Content:

1 pc Charging Station

8 pcs Charging Adaptor plugs for different devices:

- 3 x Apple Lightning Connector for Apple iPhone, iPod
- 1 Apple 30pins Connector for Apple iPhone, iPod
- 2 x Micro USB Connector for Mobile Phones
- 2 x Type C Connector for Mobile Phones
- 1 pc Installation Supplementary Sheet
- 1 set of Screws & Studs
- 1 set of Cable Ties

#### (E) Installation



E1. Fix screw studs on wall according to the installation supplementary sheet.

3 Page

1 Page

(F) Care, Maintenance, Storage and Transport



ATTENTION! There is a risk of electric shocks and short circuit!

- · The device is maintenance-free.
- · Always disconnect the mains plug from mains at first!
- · Use a dry linen cloth to clean your product, or use a slightly moist cloth for heavy stains. Look out for live cables of your device during cleaning! Do not use any cleaning supplies and avoid liquid entry to the device.
- · Avoid the risk of stumbling during installing the mains Power Cord and adaptor plugs
- · Avoid places with high temperatures, humidity, or places which can become wet, also during care, maintenance, storage and transport,
- · Mind the notes on safety also regarding care, maintenance, storage and transport
- . Use the original packaging as protection from dust and humidity for transporting.

# (G) Troubleshooting:

Problem	Help
The device does not charge	When the device is charged completely, no charging is shown.     Check all connections for tight fitting.     Use only the fitting Charging Adaptor Plugs.
Other problems	Consult your dealer.


## (H) Specifications:

Model	CLWLB14
Input Voltage	100~240V AC / 50~60 Hz
AC Adaptor Output	18V/4A
Output Voltage (Charging Adaptors)	5V
Output Current	8 x 1.5A
Output top side of housing	4 x Changeable Ports
Weight without AC Adaptor	9.5kg
Height	1039mm
Length & Width	550x45mm

- The manufacturer is not liable for damages to persons or property caused by improper installation or operation not described in this guide. This includes, among others, any alternation and modification of the product and its accessories
- · Any use other than described in this user manual is not permitted, and causes loss of warranty, loss of guarantee, and non-liability.
- . We reserve our right for misprints and changes of the device, packing or user manual.

#### Note on Waste Disposal:

Electrical and electronic equipment must not be disposed with consumers waste. The consumer is committed by law to reposit electrical and electronic devices to public collecting points or to the dealer at the end of the devices lifetime for free. Particulars are regulated in national right. The symbol on the product, in the manual or at the packaging alludes to these terms. With this kind of application of used devices you achieve an important share to environmental protection.




5 Page


6 Page


2 Page

7 Page

Step 1.
Remove front panel from the acylic charging station.








Step 3.
Connect the lightbox to the charging station.





Step 4.
Fix Charging Station on the wall.
Add spacers (C1,C2) when necessary



