












ASSEMBLY INSTRUCTIONS

	Wing screws M5*40	2 PCS		Bearing	2 PCS
	Screws $\phi 6*40*M5$	2 PCS		Spanner#8	1 PC
	Lock nut M5	2 PCS		Allen Key#3	1 PC
	Screws M5*35	4 PCS		Allen Key#4	1 PC




STEP 1

Install the Aluminum rod through the base and tighten with M5*35 screw.



STEP 2

Put the bearing into the bearing sleeve on the side of the box. Using $\phi 6*40*M5$ screw through the Aluminum rod and the bearing, then tighten lock nut. The tightness of the nut should be moderate.



STEP 3

Install the wing screws on both side of the Aluminum rod.